



3

### Congratulations !

You are now the proud owner of the AP1000 - a protective case with built-in battery for your iPhone 3G

Energizer provides Energi To Go™ for all your mobile electronic devices. Go to [www.xpalpower.com](http://www.xpalpower.com) for information on other products that can power your electronic devices.

**IMPORTANT!**  
Product Warranty Registration  
In order to activate you product warranty you must register your product at [www.xpalpower.com](http://www.xpalpower.com).



5

1. Durable protective case with built-in battery
2. Non-slip case grips
3. Smart LED battery life indicator
4. Mini USB input charge port.  
(Power only function - No data syncing)
5. Battery life indicator button
6. 30 pin iPhone power connector

10

**Energizer**  
ENERGI TO GO

Telephone: 209-578-9918  
e-mail: [support@xpalpower.com](mailto:support@xpalpower.com)  
web: [www.xpalpower.com](http://www.xpalpower.com)

**XPAL**  
POWER

9

### Maintenance

To keep your AP1000 running at its best, make sure to do the following:

1. re-charge once every three months when not in use.
2. Keep AP1000 dry and away from moisture.
3. Please do not wash the AP1000 .

### Warranty

All products have a 3 year limited warranty from date of purchase. Register online at [www.xpalpower.com](http://www.xpalpower.com) to activate and learn more about your warranty.

### Returns

ALL RETURNS! You must contact [returns@xpalpower.com](mailto:returns@xpalpower.com) before returning any product or call 209-578-9918

8

### Important

*Please read the following carefully before using the AP1000 Product. Incorrect use or incompatibility with your device may result in reduced battery performance or damage to your device.*

- Do not attempt to disassemble product or replace any part of this battery.
- Store and operate between 0-45°C
- Do not allow this product to contact liquids.
- Do not place this product near a heat source or flame.
- Do not throw or shake the power pack violently.
- Do not operate the power pack if it has been subjected to shock or damage.
- Do not crush or puncture the battery.
- Recharge the power pack every 3 months when not in use. Use soft cloth to clean the exterior. Do not use harsh chemicals or strong cleaning solvents.
- Dispose of product properly and in accordance to local disposal regulations.

